


















Part list for 4m PVC Party Tent


Part No.		6m	8m	10m
1	 2100mm	8	10	12
2	 1940mm	9	12	15
4	 1880mm	8	10	12
5 (A)	 120°	6	6	6
6 (B)	 120°	6	9	12
7		8	10	12
8		36	42	48
9		86	102	118
11		50	64	78
12		8	10	12
13		4	4	4
14		1	1	1
15		6	8	10

Part list for 4m PVC Party Tent



Part No.		6m	8m	10m
17		4	4	4
18		1	1	1
19		1	1	1





A




B





C



D



E



F

